

TROUBLESHOOTING

My T15™ is leaking from my new Remote Backplate Adapter

Fill up a spray bottle with soapy water and spray on area that you believe is leaking. The solution will bubble up where the leak is occurring. Once you identify the leak, remove the Remote Backplate Adapter, double check placement of mounting screw o-ring. Once leak is fixed, wipe off excess soapy water with a rag damp with paintball gun oil.

My fittings are leaking

Remove all fittings and reapply teflon tape.

My T15 doesn't cycle fully (it sputter fires) now that I'm running a remote.

Some remotes restrict the airflow to the T15™. To combat this, you will need to raise the output pressure of your tank. For optimum functionality, use 850-950psi output pressure.

Thank you for purchasing the First Strike T15 Remote Backplate Adapter. Like all paintball markers, please remove all air sources prior to servicing.

If you have any questions regarding this product or other First Strike Paintball products, please contact us.

FIRST STRIKE®

Headquarters:

28101 Ballard Dr. Ste. F
Lake Forest, IL 60045

Manufacturing/Warranty

2717 Ferguson Rd
Fort Wayne, IN 46809

→ 1-260-478-2500

→ service@first-strike.com

→ FIRST-STRIKE.COM

SUBSCRIBE & FOLLOW US



You must be at least 18 years of age to purchase this product. This product may be mistaken for a firearm by law enforcement officers or others. Altering the color of the product or brandishing the product in public may be dangerous and may be considered a crime.

⚠ WARNING! PAINTBALL GUNS AND PAINTBALL GUN ACCESSORIES ARE NOT TOYS!

- Careless use or misuse may result in serious bodily injury or death!
- Eye protection designed for paintball must be worn by the user and all persons within range.
- Not for sale to persons under 18 years of age.
- Must be 18 years of age or older to operate or handle any paintball gun and paintball gun accessories without adult or parental supervision.
- Read and understand all cautions, warnings, and operating manuals before using any paintball gun or paintball gun accessory.
- Do not aim paintball gun at eyes or head of people or at animals.
- Paintball guns are to be used with paintballs only.
- Use common sense and have fun.

Any tampering with the unit voids your warranty. There are no consumer serviceable parts inside the unit. The use of non factory authorized components within this product may cause a critical failure, fire or shock hazard.

IN NO EVENT SHALL SELLER BE LIABLE FOR ANY DIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM ANY DEFECTIVE PRODUCT OR THE USE OF ANY PRODUCT.

WARNING: This product does contain chemicals known to the State of California to cause cancer and/or birth defects or other reproductive harm. Wash hands after handling. You must be at least 18 years of age to purchase this product. This product may be mistaken for a firearm by law enforcement officers or others. Altering the color of the product or brandishing the product in public may be considered a crime.



FIRST STRIKE®

T15™ REMOTE BACKPLATE ADAPTER


First Strike is a brand of United Tactical Systems, LLC.

CONTENTS:


- Remote Backplate Adapter
- Q/D Swivel
- Pro Fill Nipple

YOU WILL NEED THE FOLLOWING ITEMS:


- 1/8" hex key
- 3/32" hex key
- 5/32" hex key
- Teflon tape
- Blue thread locker



STEP 1. Remove Stock ASA Ring using 3/32" hex key. (Fig 1)




STEP 2. Split T15™ Upper Receiver from the Lower Receiver by pushing out the front and rear trip pins. (Fig 2)




STEP 3. Remove Rear ASA Port using 3/32" hex key (Fig 3)



STEP 4. Remove stock ASA using 1/8" hex key. Keep stock ASA screws and mounting screw o-ring for installation of your Remote Backplate Adapter. (Fig 4)



STEP 5. Clean off stock ASA screws and apply blue thread locker. (Fig 5)



STEP 6. Install Remote Backplate Adapter to Lower Receiver and reinstall Stock ASA screws. (Fig 6)



STEP 7. Apply Teflon Tape to Pro Fill Nipple Adapter and place in port. Tighten using 5/32" hex key. (Fig 7)

STEP 8. Install Quick Disconnect Swivel.

STEP 9. Let sit overnight for blue thread locker to cure.