



PARTS LIST

Key	Part No.	Description
01	165469-000	Receiver assembly
02	164474-000	Bolt Assembly
03	131443-000	Retaining pin
04	164731-000	Valve body assembly
05	131220-000	Valve set screw
06	164447-000	Valve stem assembly
07	130811-000	Valve guide
08	131104-000	Valve spring
09	164472-000	Volumizer assembly
10	165470-000	Barrel assembly
11	164475-000	Striker assembly
12	131105-000	Striker spring
13	131113-000	Spacer
14	131559-000	Spring guide
15	131081-000	Bumper
16	131560-000	Striker plug
17	164476-000	Velocity adj. screw
18	132212-000	Ball stop
19	164827-000	Grip frame assembly
20	130743-000	Ball stop screws
21	131556-000	Foregrip
22	164473-000	Braided hose assembly
23	131557-000	Bottomline screw
24	131563-000	Bottomline adapter
25	130727-000	Filter
26	131562-000	Drop forward screw
27	131555-000	Drop forward
28	130815-000	Retaining screw
29	130806-000	Lock washer