



PARTS LIST

Key	Part No.	Description
01	131424-000	Barrel
02	137527-000	O-ring (Barrel)
03	131497-000	Cocking pin
04	164449-000	Receiver assembly
05	136952-000	O-ring (Bolt and valve body and volumizer)
06	164421-000	Bolt assembly
07	130731-000	O-ring (Bolt and striker)
08	130726-000	Screw (Sight rail)
09	131474-000	Sight rail
10	137627-000	Velocity adjustment screw
11	137629-000	O-ring (Vel. Adj. Screw)
12	131188-000	Striker plug
13	131081-000	Bumper
14	131101-000	Spring guide
15	131113-000	Spacer
16	131105-000	Striker spring
17	131408-000	Striker
18	131443-000	Retaining pin
19	131220-000	Valve set screw
20	130806-000	Lockwasher
21	130815-000	Screw (Grip to receiver)
22a	164452-000	Grip frame assembly (Chang-Po)
23	131423-000	Bottomline adapter
24	130727-000	Filter screen
25	131087-000	Screw (Bottomline)
26	130739-000	O-ring (Braided hose)
27	130764-000	Braided hose
28	130729-000	O-ring (Braided hose)
29	131575-000	Foregrip
30	131032-000	Ball stop
31	131033-000	Ball stop cover
32	130743-000	Screw (Ball stop)
33	131183-000	Valve body
34	164447-000	Valve stem assembly
35	130811-000	Valve guide
36	131104-000	Valve spring
37	131422-000	Volumizer